

## AccuVent for Manufactured / Modular Homes

(PN: ACBP18450, ACBP18509, ACBP18467, ACBP18616)

### **Step 1:**

Staple DriftBlocker to wall framing.\*



### **Step 2:**

Install insulation



### **Step 3:**

Layout and secure the AccuVent Manufactured Home panels to the truss.



### **Step 4:**

A taller panel or additional panels may be needed to reach top of insulation.



### **Step 5:**

Place and secure roof decking.



\* Securing of DriftBlocker may require blocking at edge to truss when using dense pack insulation.